TALK TO THE EXPERTS 1800 02

THE PROFITABLE **SOLUTION TO ROOT** INTRUSION.

LIFTING THE LID O EWER TECHNOLO

RootX comes in two convenient sizes to tackle root growth in pipes 150mm and up to 30m in length. Plumbers can choose between 908g or 1.8kg jars for either toilet or sewer cleanout applications. Follow the instructions below for a guide on how to use RootX:



TOOLS NEEDED:

- Chemical-resistant gloves
- Chemical-resistant apron
- 20ltr bucket and clean water

STEP 1: SELECT JAR SIZE AND TOOLS

Select the appropriate RootX Funnel Jar for use:

• A 908g jar will treat approximately 15m of 100mm pipe.

• A 1.8kg jar will treat

approximately 30m of 100mm, or 22.5m of 150mm pipe.

STEP 2: ATTACH THE FUNNEL

Unscrew round lid from top of container. Attach the mixing funnel/application by threading onto opening where the lid was in the square container.

STEP 3: MIX ROOTX COMPONENTS

Grasp the bottom of the square container and the narrow end of the mixing funnel applicator (putting a gloved hand over the mixing funnel cap located at the narrow end of the

mixing applicator). Rock the square container with the mixing funnel applicator attached, back and forth for approximately one minute - allowing the two dry components of RootX to flow into the funnel and back into the square container several times.

FOR MORE INFORMATION **ON THE ROOTX PRODUCT** VISIT OUR WEBSITE





STEP 4: APPLY ROOTX

After the solution is thoroughly mixed, remove the cap from the narrow end of the funnel applicator and pour the entire mixture of dry product through the funnel directly into a sewer cleanout or toilet bowl if a sewer cleanout is not available.



STEP 5A: SEWER CLEANOUT APPLICATION

Pour entire contents of RootX Funnel Jar into cleanout. Add 19ltrs of water per kilo of RootX used to push the foam down through the sewer line. (example 38ltrs of water for a 908g jar)



STEP 5B: TOILET CLEANOUT APPLICATION

Flush the toilet and add the dry mixture into the toilet bowl as the water is going down the drain. Add 19ltrs of water per kilo of RootX used



to push foam down the toilet drain. To avoid overflow, use no more than 908g jar of RootX for toilet application.



STEP 6: RESTRICT WATER USAGE Restrict water usage for 4-6 hours after application.

